



Panel Installation Instructions

For SBC682 and SBC683 Kegeerator PNR Models

Models: SBC682NKPNR | SBC682PNR | SBC682PNRCFTWIN | SBC682PNRCMTWIN
SBC682PNRNCFTWIN | SBC682PNRTRIPLE | SBC682PNRTWIN | SBC682PNRWKDTWIN
SBC683OSPNR

Your product is designed to accept custom overlay panels on its door.

Parts included in the PNR kit:

- (1) Replacement top hinge
- (1) Replacement bottom hinge
- (2) Plastic bushing for panel

Panel Dimensions:

Door Exterior: 23 ⁵/₁₆" W x 29 ³/₄" H
Overlay panel thickness: minimum ³/₄" thick



Removing the Unit's Door

1. Remove the door from its chassis by unscrewing the top and bottom hinges from the cabinet and door.

Attaching the Handle and Panel

2. Attach your door handle to the panel.
3. Pull out the rubber gasket located around the inside of the door frame to access the screw holes from the inside of the door.
4. Drill holes into the door opposite the handle.
5. Place your custom panel over the door pane.
6. Hold the panel in place from the front, then use an appropriate screw to secure it to the door frame from the inside of the door.
7. Reinstall the gasket to its original position.

Reattaching the Door

8. You will have to drill a hole into the top and bottom of the custom panel in order to connect it to the new provided hinges. To do this, line up the door in its final position and, using the hinges, mark where you will be drilling the holes.
9. Using a 3/8" drill bit, drill a hole through the top and bottom of the custom panel.
10. Insert the provided bushing into the top and bottom of the panel.

If you need help with your installation call our Customer Service facility at **800-932-4267 (Ext. 513)** between 9:00 AM and 5:00 PM ET or visit our website summitappliance.com/support at any time.

We will do our best to answer your questions.

To order replacement parts, visit our website: summitapplianceparts.com