




Use & Care Guide

Stainless Steel Stove to Counter Gap Filler

Thank you for choosing Summit Appliance!

Designed to bridge the space between your stove and countertop, this gap filler helps prevent spills, crumbs, and debris from falling through, keeping your kitchen cleaner and more hygienic. Review these care instructions for best results and long-lasting use.



Models:

TKGAPFILLER24
TKGAPFILLER25
TKGAPCUSTOM

Includes:

Stainless Steel Gap Filler (2)

Installation

1. Ensure the area between the stove and countertop is clean and dry.
2. Gently slide the gap filler into place along each side of the stove.
3. Adjust as needed for a snug fit.

Note: Suitable for gaps up to 0.75 in (19 mm) wide.

Care & Cleaning

- Remove occasionally to clean any debris that may collect underneath.
- Wipe regularly with a soft cloth and warm, soapy water.
- For stubborn spots, use a non-abrasive stainless steel cleaner or a mixture of mild detergent and water.
- Always wipe in the direction of the grain to maintain the finish.
- Rinse and dry thoroughly to prevent water spots.
- Avoid abrasive pads, steel wool, chlorine-based cleaners, or harsh chemicals, as they can damage the surface.

If you need help with your installation, call our Customer Service facility at **800-932-4267 (Ext. 513)** between 9:00 AM and 5:00 PM ET or visit our website summitappliance.com/support at any time. We will do our best to answer your questions.

To order replacement parts, visit our website: summitapplianceparts.com

Summit Appliance Division · Felix Storch, Inc. · www.summitappliance.com · 718-893-3900 · info@summitappliance.com