



Remote Switch Installation For ADA Compliant European Range Hoods

NOTE: Installation and service must be performed by a qualified installer/electrician

WARNING:

To avoid fire or electrical shock, turn off power at circuit breaker or fuse.

Test to ensure that the power is off before wiring.

1. Remove the mesh filters to access the pre-wired remote switch.
2. Open the control box by removing the four screws.
3. Note the connection of the wires, then remove them by loosening the securing screws.
4. Choose a location of your choice for mounting the remote switch. The wires might need to be extended based on the distance from the hood. *NOTE: If installing this switch in accordance with ADA guidelines, the height of the light switch must be no lower than 15" from the floor and no higher than 48" from the floor. Additional regulations apply if there are any obstructions in front of the switch. For more information, refer to Section 308 of the most recent ADA Standards for Accessible Design at ada.gov.*
5. Reconnect the wires in the control box.
6. Close the control box by re-inserting the screws.

For technical assistance, please contact us at 7180893-3900 ext. 597/ techsupport@summitappliance.com