



MRF Microwave Braces' Installation Instructions

The microwave support braces attach to both the microwave and the refrigerator or freezer with detachable adhesive. The microwave can only be installed in one place on the top of your refrigerator or freezer, but it will still be removable after installation.

In the box you will find:

- 2 L-braces, with detachable adhesive
- Installation instructions

- 1) Place the braces on the left and the right side of the rear of the microwave. The longer side of the brace should rest against the metal strip along the bottom of the microwave, pictured to the right.
- 2) Remove the plastic backing of the detachable adhesive on the vertical side of the brace
- 3) Press the brace firmly against the microwave, attaching the exposed side of the adhesives.
- 4) Locate an appropriate spot for your microwave on top of your refrigerator or freezer.
- 5) Remove the plastic backing of the detachable adhesive on the horizontal side of the brace.
- 6) Press the brace firmly against the top of your refrigerator or freezer, attaching the exposed side of the adhesives.
- 7) The microwave is now installed.

