



## **BUILT-IN REFRIGERATOR**

**Models: SPR623OS**

**SPR623OSCSS**

### *Owner's Manual*

**BEFORE USE, PLEASE READ AND FOLLOW  
ALL SAFETY RULES AND OPERATING INSTRUCTIONS**

Write Serial Number here:

\_\_\_\_\_

**Felix Storch, Inc.  
An ISO 9001:2015 registered company  
Summit Appliance Division  
770 Garrison Avenue  
Bronx, NY 10474  
[www.summitappliance.com](http://www.summitappliance.com)**

# TABLE OF CONTENTS

<b>Important Safety Instructions</b> .....	<b>3 – 4</b>
<b>Installation Instructions</b> .....	<b>5 – 6</b>
Before using your appliance .....	5
Installation of your appliance .....	5
Reversing the door swing .....	6
<b>Operation</b> .....	<b>7 – 8</b>
Recommended temperatures for chilling wine .....	7
The controls of your appliance .....	7 – 9
<b>Care and Maintenance</b> .....	<b>10</b>
Cleaning your appliance	
Defrosting	
Power failure	
Vacations	
Transporting your appliance	
Energy-saving tip	
<b>Problems with Your Appliance</b> .....	<b>11</b>
<b>Limited Warranty</b> .....	<b>12</b>

# IMPORTANT SAFETY INSTRUCTIONS

**⚡WARNING⚡** To reduce the risk of fire, electrical shock, or injury when using your appliance, follow these basic precautions

## **Read all instructions before using the appliance:**

- Plug into a grounded 3-prong outlet. Do not remove the grounding prong, do not use an adapter, and do not use an extension cord.
- It is recommended that a separate circuit, serving only your appliance, be provided. Use an electrical outlet that cannot be turned off by a switch or pull chain.
- Never clean parts of this unit with flammable fluids, these fumes can create a fire hazard or explosion.
- Before proceeding with cleaning and maintenance operations, make sure the power line of the unit is disconnected.
- Do not connect or disconnect the electric plug when your hands are wet.
- Unplug the appliance or disconnect the power before cleaning or servicing, failure to do so can result in electrical shock or death.
- Do not attempt to repair or replace any part of your appliance unless it is specifically recommended in this manual. A qualified technician should complete all other servicing.
- Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion.
- Use two or more people to move/install the appliance, failure to do so can result in back or other injuries.
- To ensure proper ventilation for your appliance, the front of the unit must be completely unobstructed. Choose a well-ventilated area with temperatures above 61°F (16.1°C) and below 95°F (35°C). This unit must be installed in an area protected from the elements, such as wind, rain, water spray, or drips.
- The appliance should not be located next to ovens, grills, or other sources of high heat.
- The unit must be installed with all electrical connections in accordance with state and local ordinances. This unit uses the standard electrical supply (115 VAC, 60 Hz) and must be properly grounded in accordance with national and local codes and ordinances.
- Do not kink or pinch the power supply cord of the appliance.
- The fuse (or circuit breaker) size should be 15 amps.

- This appliance needs to be leveled for it to work properly. You may need to make several adjustments to level it.
- Although the unit has been tested at the factory, due to transit and storage, you should clean the appliance before use.
- Do not use solvent-based cleaning agents or abrasives on the interior. These cleaners may damage or discolor the interior.
- Do not use this apparatus for other than residential purposes.
- This appliance is CFC and HFC free and contains small quantities of Isobutane (R600a) which is environmentally friendly, but flammable. It does not damage the ozone layer or increase the greenhouse effect. Care must be taken during transportation and setting up of the appliance so that no cooling system parts are damaged. Leaking coolant can ignite and may damage the eyes.
- In the event of any damage:
  - Avoid open flames and anything that can create a spark,
  - Disconnect from the electrical power line,
  - Ventilate the room in which the appliance is located for several minutes and contact the Service Department for advice.
- The more refrigerant there is in an appliance, the larger the room it should be installed in. In the event of a leakage, if the appliance is in a small room, there is the danger of combustible gases building up. For every ounce of coolant, at least 325 cubic feet of room space is required. The amount of coolant in the appliance is stated on the data plate on the back of the appliance.
- It is hazardous for anyone other than an authorized Service Person to carry out servicing or repairs to this appliance.
- Take serious care when handling, moving, and using the appliance to avoid either damaging the refrigerant tubing or increasing the risk of a leak.
- Replacing component parts and servicing shall be done by factory authorized service personnel to minimize the risk of combustion due to incorrect parts or improper service.

**DANGER!** *Risk of child entrapment*

Child entrapment and suffocation are not problems of the past. Junked or abandoned appliances are still dangerous, even if they will “just sit in the garage a few days.”

- **Before you throw away your old refrigerator or any appliance:** Remove the door. Leave the shelves in place so that children may not easily climb inside.
- Never allow children to operate, play with, or crawl inside the appliance.

**CALIFORNIA CARB/SNAP DISCLOSURE**

**This product uses eco-friendly hydrocarbon refrigerant and fully complies with California CARB regulations.**

However, we are required by California Law to provide the following disclosure statement in every product sold in California.

*"This equipment is prohibited from use in California with any refrigerants on the 'List of Prohibited Substances' for that specific end-use, in accordance with California Code of Regulations, title 17, section 95374. This disclosure statement has been reviewed and approved by Felix Storch, Inc. and Felix Storch, Inc. attests, under penalty of perjury, that these statements are true and accurate."*

This product does **not** use any refrigerants on the 'List of Prohibited Substances'"

**- SAVE THESE INSTRUCTIONS -**

# INSTALLATION INSTRUCTIONS

## **Before Using Your Appliance**

- Remove the exterior and interior packing.
- Before connecting the appliance to the power source, let it stand upright for approximately 2 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation.
- Clean the interior surface with lukewarm water using a soft cloth.
- Install the handle, stored inside the unit. Install using the supplied screws.

## **Installation of Your Appliance**

- This appliance is designed for freestanding or built-in (fully recessed) installation. If freestanding, the unit should have at least 4in of clearance at both sides, at the top, and at the back to allow for adequate ventilation. If it is built-in, leave 3/16 inches at both sides, 1/16 inches at the top, and 2 inches at the rear. Be sure that airflow under the appliance is not blocked.
  - Place your appliance on a floor that is strong enough to support it when it is fully loaded. To level your appliance, adjust the front leveling legs at the bottom.
  - Locate the appliance away from direct sunlight and sources of heat (stove, heater, radiator, etc.). Direct sunlight may affect the acrylic coating and the heat may increase electrical consumption. Extremely cold ambient temperatures may also cause the unit not to perform properly.
  - Avoid locating the unit in moist areas.
  - Plug the appliance into an exclusive, properly installed, and grounded wall outlet. Do not under any circumstances cut or remove the third (grounding) prong from the power cord. Any questions concerning power and/or grounding should be directed toward a certified and authorized products service center.
-

## **Reversing the Door Swing**

This unit can have its door open from the left or right. The default option is to open from the left, but if you want to reverse the direction of the door, please follow the instructions below:

To make the reversal, look inside the appliance to find the top left hinge and bottom left hinge. The bottom support bracket is used when the door opens from either side.

1. Carefully lay the appliance on its back. Use cushioning to protect the floor and the unit.
2. Using a Phillips screwdriver, remove the two screws on the bottom right hinge at the bottom of the door. Keep the hinge in a safe place in case you need to reverse the door again in the future.
3. Carefully slide the door off and place it on a padded surface.
4. Interchange the plastic shaft sleeves at the top of the door.
5. Remove the bottom support bracket from the right side.
6. Remove the top right hinge
7. Remove the screws from the top left and transfer them to the right.
8. Install the top left hinge.
9. Install the bottom left hinge to the door. **DO NOT OVERTIGHTEN THE SCREW.**
10. Place the door back on the appliance, lining up the top hinge.
11. Install the bottom support bracket.
12. Adjust door alignment. When set, tighten the screws on the hinge.
13. Remove the handle. Transfer the screw hole covers to the left, then install the handle on the right.

**NOTE:** keep the other hinge in a safe place in case you want to reverse the door in the future.

# OPERATION

## The Controls of Your Appliance

This appliance should be placed somewhere where the ambient temperature is between 16-35°C (60.8 - 95°F). If the ambient temperature is above or below this range, the performance of the unit may be affected. Placing your unit in extremely cold or hot conditions may cause interior temperatures to fluctuate.

## Control Panel



## Setting the temperature Control

- Adjustable temperature: 2°C to 8°C (35.6°F to 46.4°F)

- Set the desired temperature by pressing the corresponding buttons, to increase or to decrease. Each press is a 1-degree increment or decrement. Once released, the set temperature will flash for approximately 5 seconds, then revert to display the internal temperature.
  - To view your set temperature, press either the or button once and the LED display will flash the set temperature for 5 seconds.
  - This appliance can display temperatures in either Celsius or Fahrenheit. To change the temperature scale, press and hold both buttons simultaneously for approx. 3 seconds.
- Note:** The temperature inside may vary slightly depending on whether the interior bulb is ON or OFF and where the bottles are located.

<b>ECO mode:</b>	<ul style="list-style-type: none"> <li>Press and hold the button  for 3 seconds to enter or exit ECO mode.</li> <li>In this mode, the interior LED light, the compressor indicator  and the temperature value on the display panel will be turned off and the ° symbol will be illuminated in the upper left corner when the temperature is being displayed.</li> </ul>
 <b>Light / Lock</b>	<ul style="list-style-type: none"> <li>LED lamp brightness mode: with Memory IC (when the unit restarts after power failure unit, it will auto recover to the last setting), the default brightness is 100%. Each time the button  is pressed, the brightness of the LED will be cycled through the four positions (100%, 75%, 50%, OFF)</li> <li>Press and hold for 3 seconds to lock or unlock the control panel.</li> </ul>
 <b>ON/OFF Power / Mute</b>	<ul style="list-style-type: none"> <li>To turn the appliance on or off, press and hold the ON/OFF button for 3 seconds.</li> <li>When the high/low-temperature alarm is activated, the buzzer will sound continuously. Press  once time to turn off the alarm.</li> </ul>
 <b>LOCK</b>	<p>If illuminated, this indicates the control panel is locked.</p>
 <b>RUN</b>	<p>When the unit's compressor is running, this indicator light will illuminate to signify that cooling mode is currently in operation.</p>
<b>Demo mode</b>	<ul style="list-style-type: none"> <li>Press and hold buttons ,  and  simultaneously for 10 seconds to enter or exit demo mode.</li> <li>In this mode, the display panel can operate settings, but the temperature is a fixed display of 12°C (54°F), and all fans, including, the compressor will not start.</li> </ul>
<b>Sabbath mode</b>	<ul style="list-style-type: none"> <li>Press and hold buttons  and  at the same time for at least 5 seconds to enter or exit Sabbath mode. In this mode, LED will display "Sb". This mode turns off the displays, and interior lights and prevents them from turning on again. Normal cooling operations will still take place. The compressor and the fan work normally.</li> </ul> <p>While the cabinet's power is off, it will not automatically exit Sabbath mode, and it will keep Sabbath mode when it powers on again. The Sabbath Mode will automatically turn off after 96 hours.</p>
<b>Defrosting</b>	<ul style="list-style-type: none"> <li>This unit defrosts automatically in normal operating conditions.</li> <li>The evaporator behind the rear wall of the unit defrosts automatically. Water will drain through the drainpipe from the back of the product. Users need to bring the water to the drain or find an appliance to load the water. (If loading with an appliance, you need to pay attention to clearing the water regularly)</li> <li>However, frost may accumulate on the evaporator if the unit is repeatedly opened in high heat or high humidity location. If this frost pattern does not clear within 24 hours, your unit will require manual defrosting.</li> </ul>
<b>Mandatory defrost mode:</b>	<p>Press the  and  at one time for 10 seconds to enter compulsory defrost mode.</p>

**NOTE:**

- If the unit is unplugged or turned off, or if there has been a power failure, you must wait 5 minutes before restarting the unit. If you attempt to restart before this time delay, the appliance will not start.
- When you use the appliance for the first time or restart it after it has been shut off for a long time, there could be a few degrees variance between the temperature you select and the one indicated on the display. This is normal due to the length of inactivity. Once the appliance has been running for a few hours, everything will be back to normal.

**Temperature Alarm Function**

If the ambient temperature is  $\geq 30^{\circ}\text{C}$  ( $86^{\circ}\text{F}$ ) for 2 hours, the high-temperature alarm will be activated, the LED will display "HH", the buzzer will sound continuously, and the cooling system will continue to work. The display will return to normal once your unit stabilizes at working temperatures.

If the ambient temperature is  $< 0^{\circ}\text{C}$  ( $32^{\circ}\text{F}$ ) for 1 hour, the low-temperature alarm will be activated, the LED will display "LL", the buzzer will sound continuously, and the cooling system will stop working. The display will return to normal once your unit stabilizes at working temperatures.

**NOTE:**

- It is normal if the cabinet shows "HH" or "LL" from time to time. If it occurs frequently or lasts for a long time, you can restart the unit by unplugging it, then re-plugging it after 5 minutes. If the problem occurs again after restarting, please contact customer service.
- Before reconnecting the power, wait for 3 to 5 minutes. Otherwise, you could damage your appliance. If you attempt to start the appliance before the end of this time delay, the appliance will not turn on.

# CARE AND MAINTENANCE

## **Cleaning Your Appliance**

1. Turn off the power, unplug the appliance, and remove all items including shelves and racks.
2. Wash the inside surfaces with a warm water and baking soda solution. The solution should consist of about 2 tablespoons of baking soda to a quart of water.
3. Wash the shelves with a mild detergent solution.
4. Wring excess water out of the sponge or cloth when cleaning the area of the controls or any electrical parts.
5. Wash the exterior of the unit with a warm solution of mild liquid detergent. Rinse well and wipe dry with a clean, soft cloth.
6. For stainless steel surfaces, routine cleaning can be accomplished by using warm water and a cloth. Dry with a towel or cloth to prevent water spots. Wipe in the directions of the brush lines. For a stronger cleansing, you can use a mild detergent in warm water. Make sure to rinse the surface thoroughly to prevent staining and spotting. Towel dry.

## **Defrosting**

Defrosting of the inside of the appliance occurs automatically during operation. Approximately every 8 hours, the compressor will stop running for about 30 minutes. During defrosting the temperature will be higher than you set. The defrost water is collected by the evaporating tray above the compressor and evaporates automatically.

## **Power Failure**

Most power failures are corrected within a few hours and should not affect the temperature of your appliance if you minimize the number of times the door is opened. If your power is going to be off for a longer period, you need to take the proper steps to protect the contents inside your unit.

## **Vacations**

Leave the appliance operating during vacations of less than three weeks. If you turn off the appliance for extended periods, leave the door slightly ajar to prevent odor from building up inside.

## **Transporting Your Appliance**

If you need to move your appliance once the box has been discarded:

1. Securely tape down all loose items (i.e.: shelves) inside your appliance.
2. Turn the adjustable legs up to the base to avoid damage.
3. Tape the door shut.
4. Be sure the appliance stays secure in the upright position during transportation. Also, protect the outside of the appliance with a blanket or similar item.

## **Energy-Saving Tip**

The appliance should be located in the coolest area of the room, away from heat-producing appliances and out of direct sunlight.

## PROBLEMS WITH YOUR APPLIANCE

You can solve many common problems easily, saving you the cost of a service call. Try the suggestions below to see if you can solve the problem before calling for service.

### TROUBLESHOOTING GUIDE

PROBLEM	POSSIBLE CAUSE	REMEDY
Appliance does not operate.	<ul style="list-style-type: none"> <li>• The unit defrosts automatically in normal operating conditions.</li> <li>• The appliance is turned off.</li> <li>• Tripped circuit breaker or a blown fuse.</li> </ul>	<ul style="list-style-type: none"> <li>• Connect the appliance.</li> <li>• Switch on the appliance.</li> <li>• Switch on the circuit breaker or replace the fuse.</li> </ul>
Appliance is not cold enough.	<ul style="list-style-type: none"> <li>• The temperature is not set correctly.</li> <li>• The ambient temperature could require a lower temperature setting.</li> <li>• The condenser is too dirty.</li> <li>• The ventilation opening is blocked or too dusty.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the set temperature.</li> <li>• Set a lower temperature.</li> <li>• Clean the condenser when necessary.</li> <li>• Clear the obstructions and wipe off the dust.</li> </ul>
Appliance turns itself on and off frequently.	<ul style="list-style-type: none"> <li>• The room temperature is higher than average.</li> <li>• A large number of items have been added to the unit.</li> </ul>	<ul style="list-style-type: none"> <li>• Put the appliance in a cooler place.</li> <li>• Leave the appliance to work for a while until the set temperature has been reached.</li> </ul>
The light does not work.	<ul style="list-style-type: none"> <li>• Appliance is not connected to a power supply.</li> <li>• Tripped circuit breaker or a blown fuse.</li> <li>• The light was switched off on the control panel.</li> </ul>	<ul style="list-style-type: none"> <li>• Connect the appliance.</li> <li>• Switch on the circuit breaker or replace the fuse.</li> <li>• Switch on the light.</li> </ul>
Vibrations	<ul style="list-style-type: none"> <li>• The appliance is not properly level.</li> </ul>	<ul style="list-style-type: none"> <li>• Level the appliance using the adjustable feet.</li> </ul>
The appliance seems to make too much noise.	<p>The rattling noise may come from the flow of the refrigerant, which is normal. As each cycle ends, you may hear gurgling sounds caused by the flow of refrigerant in your appliance.</p> <p>If temperature fluctuations occur, the contraction and expansion of the inner walls may cause popping and crackling noises.</p>	
	<ul style="list-style-type: none"> <li>• The appliance is not properly level.</li> </ul>	<ul style="list-style-type: none"> <li>• Level the appliance using the adjustable feet.</li> </ul>
Display “E1”, “E2”.	<ul style="list-style-type: none"> <li>• “E1” or “E2” indicates that the air temperature sensor has failed.</li> </ul>	<ul style="list-style-type: none"> <li>• Call for service.</li> </ul>

# NOTES

# LIMITED WARRANTY

## ONE-YEAR LIMITED WARRANTY

Within the 48 contiguous United States, for one year from the date of purchase, when this appliance is operated and maintained according to instructions attached to or furnished with the product, the warrantor will pay for factory specified parts and repair labor to correct defects in materials or workmanship. A designated service company must provide service. Outside the 48 states, all parts are warranted for one year from manufacturing defects. Plastic parts, shelves, and cabinets are warranted to be manufactured to commercially acceptable standards and are not covered from damage during handling or breakage.

## 5-YEAR COMPRESSOR WARRANTY

1. The compressor is covered for 5 years.
2. Replacement does not include labor.

### **ITEMS WARRANTOR WILL NOT PAY FOR:**

1. Service calls to correct the installation of your appliance, to instruct you how to use your appliance, to replace or repair fuses, or to correct wiring or plumbing.
2. Service calls to repair or replace appliance light bulbs or broken shelves. Consumable parts (such as filters) are excluded from warranty coverage.
3. Damage resulting from accident, alteration, misuse, abuse, fire, flood, acts of God, improper installation, installation not in accordance with electrical or plumbing codes, or use of products not approved by the warrantor.
4. Replacement parts or repair labor costs for units operated outside the United States.
5. Repairs to parts or systems resulting from unauthorized modifications made to the appliance.
6. The removal and reinstallation of your appliance if it is installed in an inaccessible location or is not installed in accordance with published installation instructions.

## DISCLAIMER OF IMPLIED WARRANTIES-LIMITATION OF REMEDIES

CUSTOMER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR AS PROVIDED HEREIN. IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR. WARRANTOR SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS, SO THESE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

**WARNING: This product can expose you to chemicals including Nickel**



**Metallic) which is known to the State of California to cause cancer.**

For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

**FELIX STORCH, INC.**  
**770 Garrison Avenue**  
**Bronx, NY 10474**  
**Phone: (718) 893-3900**

For parts and accessory ordering,  
troubleshooting, and helpful hints, visit:  
[www.summitappliance.com/support](http://www.summitappliance.com/support)

**SUMMIT**<sup>®</sup>

Printed in China