

Instructions: Replacing the 6-bottle cover with an 8-bottle cover



Remove 12 screws around the cover using a Phillips screwdriver.

Carefully lift off the 6-bottle cover.



Install (3) Z-clips on front side only, securing each with a screw.

Set the enclosed 8-bottle cover in place so that the Z-clips are concealed by front edge of cover.



From below, align three screws with the Z-clips and screw them in.

Secure the ends with 2 screws each.

Secure the back of the cover with 5 screws. Installation is complete.

NOTE: Use and care instructions for model STC1W6 can be found in the enclosed Instruction Manual for model STC1. You have the option of replacing the 6-bottle cover of model STC1W6 with the enclosed 8-bottle cover by following the instructions on this page. This converts the unit to model STC1.